

FILM INSTALLATION INSTRUCTIONS:

This film must be installed as indicated, one of the surface can be treated with either anti-dust, anti-condensation or thermal. If imprint on the film indicates "inside", you should be able to read it from the inside of the greenhouses.

Please note: While installing the film the exposed side of the roll must make contact with the roof (facing down). The internal side of the roll should be facing upwards. For best results and to insure proper use of the film please follow installation instructions carefully.

IMPORTANT: It has been observed that if during placement over the greenhouse the film is often unrolled and unfolded simultaneously. By doing so, it is possible to damage it by bundling the internal folds and having them harmed or even torn by excessive pressure

In order properly install the films, it is important to follow the instructions below:

- 1- First unroll the full length of the film either on the roof of the greenhouse or on the ground, **without unfolding it !**
- 2- After unwinding the whole roll, unfold first the two top ends towards the sides (left and right).
- 3- If the film has been unrolled on the roof of green house: unfold now the two sides that remain folded.
- 4- If the film has been unrolled on the ground, take the cut end that is next ti the side of the green house and drive it over to the opposite side of the greenhouse.
- 5- having unfolded the film according to the instructions, tension it and fix it on the structure

Preferably the film should be installed when temperature is between 10 to 22 deg C (50 to 72 deg F).

